

Communication software
for Stepper Motor Power Stages
with ServiceBus



ServiceBus-Comm[®]

**Communication Software for
Stepper Motor Power Stages
with ServiceBus**

© 2008

All rights with:

Phytron GmbH

Industriestraße 12

82194 Gröbenzell, Deutschland

Tel.: +49(0)8142/503-0

Fax: +49(0)8142/503-190

Every possible care has been taken to ensure the accuracy of this technical manual. All information contained in this manual is correct to the best of our knowledge and belief but cannot be guaranteed. Furthermore we reserve the right to make improvements and enhancements to the manual and / or the devices described herein without prior notification.

We appreciate suggestions and criticisms for further improvement. Please send your comments to the following e-mail address: doku@phytron.de

Contents

1	What is ServiceBus-Comm® ?	4		
2	System Requirements	4		
3	Software Installation	5		
3.1	File Names	7		
3.2	Update of ServiceBus-Comm®	7		
3.3	USB Driver	7		
3.4	CAN Bus	7		
4	The Working Environment Used by ServiceBus-Comm	8		
5	The ServiceBus-Comm® Menus	10		
5.1	Starting and Leaving ServiceBus-Comm®	10		
5.2	The Menu <i>File</i>	10		
5.2.1	New 	10		
5.2.2	Open 	11		
5.2.3	Save  	12		
5.2.4	Save as	12		
5.2.5	Close	12		
5.2.6	Print 	12		
5.2.7	Exit	12		
5.3	The Menu <i>View</i>	12		
5.4	The Menu <i>Power stage</i>	13		
5.4.1	Search 	13		
5.4.2	Reset Power Stage 	18		
5.4.3	Sub menu <i>Settings TEO</i> (for PAB+ only)	18		
5.4.4	Sub menu <i>Status Power stage>></i>	19		
5.4.5	Sub menu <i>Status TEO>></i> (for PAB+ only)	21		
5.4.6	Status Overview	21		
5.4.7	Project	22		
5.5	The Menu <i>Options</i>	23		
5.5.1	Interface Parameters	23		
5.5.2	Monitor	26		
5.5.3	Language	26		
5.6	The Menu <i>Windows</i>	27		
5.6.1	Cascading Windows	27		
5.6.2	Tile Windows	28		
5.6.3	Place Symbols	28		
5.7	Menu <i>Help</i> 	28		
5.7.1	About ServiceBus-Comm®	28		
5.7.2	Help	28		
6	Error Messages	29		
7	USB Driver Installation	30		
8	Copyright and Limitation of Warranty	31		
9	Index	32		

1 What is ServiceBus-Comm[®] ?

ServiceBus-Comm is WINDOWS software for simple parameterizing and operating of phytron stepper motor power stages with ServiceBus by means of a PC.

The operating parameters like run current, stop current, step resolution, current delay time or other power stage parameters are set up on a PC, saved and transmitted to the power stage via ServiceBus.

ServiceBus-Comm supports during operation for example the monitoring of run current, motor or power stage temperature. The status display informs about the input states and allows setting outputs or displaying error messages.

Up to 32 stepper motor axes can be managed simultaneously by ServiceBus-Comm.

The Main Features of ServiceBus-Comm[®] in One View

- Desktop with drop-down menus and graphical user interface
- Hotkeys for frequently used commands
- Menu dialogue in 2 languages (German and English)
- Dynamic allocation of PC resources means, ServiceBus-Comm will only occupy the memory space needed at that time.
- Simple and fast parameter settings of the power stages
- Parameter saving in a file or a project file
- Old power stage parameters are comparable with new ones
- Upgradable for new power stage developments


2 System Requirements

ServiceBus-Comm can be used on PCs with at least the following features:

- Pentium 100 MHz
- Operating system Windows[®] 95, 98, 2000, NT, ME or XP
- At least 32 MB RAM free memory
- Windows Explorer 5 (or later)
- Mouse
- CD-ROM drive, in case of CD program installation
- Free interface RS485 (4-wire connection), USB or CAN (2-wire connection)

3 Software Installation

1. Put the program CD into the CD-ROM drive.
2. If the autostart program doesn't start automatically, open the phytron installation program [CD-ROM-address]\Autostart.exe by mouse click.
3. Phytron's installation program opens the following menu:



4. Start the ServiceBus-Comm installation program by mouse click on **Install ServiceBus-Comm**
5. The installation program copies the files into the RAM after program start.
6. The screen shows the following information:



Fig. 1: Setup program for ServiceBus-Comm

7. The following information is on screen after click on **Next >**:




Fig. 2: Setup start for ServiceBus-Comm

8. **C:\Program files\Phytron GmbH\ServiceBus-Comm** is the standard directory of ServiceBus-Comm. Another directory can be selected with **Browse ...**. Click on **Next >** to start the installation.
9. The files will be stored into the defined directory, some files will be stored into the Windows directory.
10. When the message *ServiceCommVX successfully finished* is on the desktop, the installation is successfully finished. Finish by **Close**.
11. Remove the CD from the CD-ROM drive.
12. Select: All Programs → Phytron Elektronik GmbH → ServiceBus-Comm for starting ServiceBus-Comm.

Remark:

If you have the ServiceBus-Comm files by another way (i. g. e-mail), the program installation can be done like in chapter 3.1 (beginning at item 2). Instead of CD-ROM drive select the corresponding directory, in which the file SETUP.exe is stored.

3.1 File Names

After installation the following files are stored in the directory:

ServiceBusComm.exe	Software ServiceBus-Comm
comdlg32.dll	Software library
oledlg.dll	Software library

3.2 Update of ServiceBus-Comm®

If you want to install an update in case of an existing ServiceBus-Comm copy, the installation program automatically deletes the old version before installing the new.

3.3 USB Driver

When the power stages are connected to the PC by USB interface, the USB drivers of the phytron-CD have to be installed on the PC (see chapter 7).

Important:

Administrator authorizations are required for driver installation.

3.4 CAN Bus

The CAN bus USB interface of softing company is necessary for ServiceBus-Comm in CAN bus mode to parameterize the ZMX+ power stage via PC:



Fig. 3: Softing' s CAN Bus USB interface

See www.softing.com for more information for installation and configuration.

4 The Working Environment Used by ServiceBus-Comm

The desktop will show the following work environment after the successful program start of ServiceBus-Comm.




Fig. 4: Desktop after program start

The working environment of ServiceBus-Comm consists of six main components:

1. Program name (ServiceBus-Comm)
2. The selection menu in the top line on the desktop:
File, View, Power stage, Options, Windows, Help
3. Tool bars: Selection of some commands with icons (see table)
4. The working area
5. TreeView of all open power stage files
6. The status line at the bottom of the desktop: Interface parameters (COM port, baud rate)

Icon	Meaning
	Write new parameter file .spc
	Open parameter file
	Save parameter file
	Save project parameter file
	Print parameter file
	Open help menu
	Search connection to the power stages (axes)
	Power stage reset (axis)

5 The ServiceBus-Comm® Menus

In this chapter you will find all you need for starting and leaving ServiceBus-Comm as well as a detailed description of each menu command, dialogue box, switch etc.

5.1 Starting and Leaving ServiceBus-Comm®

Select **Start / All Programs / Phytron GmbH/ ServiceBus-Comm** by clicking to program start with the left mouse key.

Use **File / Exit** to leave ServiceBus-Comm. ServiceBus-Comm will display a warning message if there is are unsaved data in one of its editor windows.

5.2 The Menu *File*

In the menu **File** you will find commands to open parameter files, to create new files, to save changed files, to print files and to leave ServiceBus-Comm.

File is the parameter file of a power stage (axis), e.g. MCD1.sdf (**servicebuscomm data file**).

A data packet of several parameter files (axes) can be pooled as **Project**, e.g. MR8-1.spf (**servicebuscomm project file**).

5.2.1 New

In the sub menu **File / New** you select a parameter file for one axis or a new project file.

In **File** you enter the power stage type and the axis name (0 to 15 or 0 to 31) to create a new parameter file.

In **Project** all open parameter files are closed.

5.2.2 Open

In the sub menu **File / Open** or **Project / Open** you can open saved parameter files or project files.

Project / Open:

When opening the project file SB-Comm compares the state of power stages connected to the axes with the saved values in the project file (e. g. MR8-1.spf).

The result is shown in the TreeView by a coloured marking of the address (=ok, =differences, =not connected/no entry in the project file).
The power stage parameters of the project file are listed at the desktop.

Example:




Fig. 5: Example for an open project file

-  **ZMX+** The project file has an entry for this axis but no power stage is connected.
-  **26** The entry in the project file accords with the connected power stage.
-  **27** Differences occur between the connected power stage and the entries in the project file for this address.
-  **28** The axis is connected but no entry in the project file.

5.2.3 Save

File / Save or **Project / Save** stores the parameter file or the project file from the active editor.

5.2.4 Save as

File / Save as or **Project / Save as** saves the data with another file name into another directory.

5.2.5 Close

File / Close closes the file in the active editor. ServiceBus-Comm remains open.

5.2.6 Print

File / Print opens the Windows specific print sub menu where you can select the printer type and the print properties.

5.2.7 Exit

File / Exit finishes ServiceBus-Comm. If files are open which are not yet saved, ServiceBus-Comm will ask you to save them.

5.3 The Menu View

In menu **View** you can define the bars for display.
The displayed bars are marked by ✓ .

Tool bar	
Status bar	Ready COM2 <Open> 9600, n, 8, 1
Power stages	TreeView in the leftmost position: display the open power stage parameter files or blank them.

5.4 The Menu *Power stage*

5.4.1 Search

ServiceBus-Comm searches for the connected power stages from axis 0 to 15 or 0 to 31. The power stages names are listed by coloured control lamps in the TreeView after a successful search:

grey		Parameter file of the axis is off line
green		Axis of the power stage is connected
yellow		Axis of the power stage is connected and a parameter file with the same axis number is open and off line
red		Axis failure: short circuit, over temperature or over voltage

The window with power stage files opens by a double click on the axis name in TreeView:




Fig. 6: Example 1: Parameter axis file is off line (control lamp: grey)




Fig. 7: Example 2: Power stage axis is connected (control lamp: green)




Fig. 8: Example 3: Power stage axis is connected (control lamp: green) and a parameter file with the same axis number is open and off line (control lamp: yellow)




Fig. 9: Example 4: Axis failure (control lamp: red)

The name of the axis is displayed in **Axis name**. The defined axis name is saved in the EPROM of the power stage by .

Run, Boost and stop current can be set in **Current setting** by the sliding switch, while the preset value is shown as a number on its right hand side.

In **Save settings** the 3 buttons fulfil the following tasks:

- | | |
|-------------------------------|---|
| Save actual parameters | The power stage parameters set on screen are saved to the power stage EPROM |
| Load basic parameters | The power stage is set to default values |
| Transmit settings | The power stage values which are set on screen are temporarily transmitted to the power stage (in off line mode only!). |

It is possible to select different operating parameters in **More power stage parameters**:

Parameters	Adjustable for power stage type						Setting
	PAB+	MR8+	MCD+	CCD+	CLD+	ZMX+	
Step resolution	1/1 to 1/256	X	X	1/1 to 1/20	X	X	1/1 to 1/512 step
Pref. motor direction	X	X	X	X	X	X	Negative/Positive
Input logic level	X	X	X	X	–	X	High / Low active
Current shape (CS)	–	X	X	–	–	–	MR8: Off / Standard Mode / Expert Mode MCD: On / Off
Input function	X	–	–	–	–	–	Boost / Activation
Current delay time	X	X	X	X	X	X	1 to 1000 ms
Activation	X	X	X	X	X	X	Activated / Deactivated
Overdrive	–	–	X	X	X	X	Off / On
Chopper frequency	–	X	–	–	X	X	50 kHz, 75 kHz or 100 kHz
Output function	X	–	–	–	–	–	Checksum / Basic position / Ready
Operation mode	–	X	X	X	X	X ¹	Bus&Switch / Bus exclusive
	X	–	–	–	–	–	Bus / Stand alone
Display menu	–	–	–	X	X	–	

The parameter values depend on the power stage type and are specified in the corresponding power stage manual.

¹ The switch status can only be read on ZMX+. The ServiceBus mode is set by the “SB active”

Explanation of the parameter operation mode:

- Bus&Switch Settings are possible both in rotary switch mode and in ServiceBus mode.
- Bus exclusive Settings only in ServiceBus mode, the rotary switches are ignored.
- Bus Bus operation mode up to 16 axes
- Stand alone Single device mode

Five axes status values are displayed in **Power stage short status** by the control lamps :

Color of 		Signification
	green	active / o.k.
	yellow	warning
	red	Error
	grey	not active / not available

Status	Control lamp  shines	
Error: Under voltage		red
Error: Over temperature		red
Error: Short circuit in power stage		red
Hardware reset (Watchdog?)		yellow
Power stage in basic position		green

Remark: Watchdog is monitoring software, which activates a reset in case of certain error status: Then, the control lamp shines yellow.

The error message is reset by .

The active power stage is reset by .

The sub menu for advanced power stage status values is started by .

Functions Temperature module TEO is subdivided (for PAB+ only):


<input type="button" value="TEO online"/> / <input type="button" value="TEO offline"/>	The temperature module TEO is operated on line or off line
<input type="button" value="TEO settings"/>	The parameters of the temperature module TEO are defined.
<input type="button" value="Reset TEO"/>	The temperature module TEO is reset.
<input type="button" value="Status TEO >>"/>	The sub menu for the temperature module TEO is open.

5.4.2 Reset Power Stage

The **active** power stage axis is reset.

5.4.3 Sub menu *Settings TEO* (for PAB+ only)

Settings for the temperature module TEO can be entered:



TEO settings

Thermocouple: Pt 100

Temperature limit 1: 100 °C

Temperature limit 2: 150 °C

Temperature limit 3: 200 °C

Temperature limit to TEO LED: Limit 1

Heat time in min.: 10 min

OK Abbrechen

Settings	Description	Values
Thermocouple	Select thermo element type	PT 100 / K-Element
Temperature limit 1	Define temperature range 1	-200 to 300 °C
Temperature limit 2	Define temperature range 2	-200 to 300 °C
Temperature limit 3	Define temperature range 3	-200 to 300 °C
Temperature limit at TEO LED	Allocate temperature limit 1,2 or 3 to the red LED	Limit 1 to Limit 3
Heat time in min.	Define the heat time of the thermocouple	5 to 300 minutes

5.4.4 Sub menu *Status Power stage*>>

The view of this sub menu depends on the type of power stage:




Fig. 10: Example: Sub menu Power stage status and test functions for PAB+

Test functions of the axis can be started by this sub menu:

1 rev. +	Turn the motor by 1 rotation clockwise
1 rev. -	Turn the motor by 1 rotation counter clockwise
Set basic position	Set the axis to basic position
Reset!	Reset the power stage

The power stage status is displayed by control lamps:

Status	Control lamp shines	
Ready		green
Unter voltage		red
Over temperature		red
Short circuit		red
Output		green
Input		green

The sum of all status values is hexadecimal coded in **Total status**.

The actual software version of the power stage is displayed in **Pwr stage - software version**.

The power stage temperature, voltage and the actual motor current are displayed in a bar chart and numerically.

5.4.5 Sub menu *Status TEO*>> (for PAB+ only)




Fig. 11: Sub menu *Status temperature module Status TEO*

5.4.6 Status Overview

The axis status is shown clearly arranged:

OK	Ready
<V	Under voltage
°C	Over temperature
Cur	Short circuit/over current
Power stage temperature	in °C




Fig. 12: Menu Status overview

32 axes can be divided in **Axis selection** into 4 ranges.

5.4.7 Project

All axes files which are set on screen are saved in the corresponding power stage files by **Project**.

5.5 The Menu *Options*

The menu *Options* is only available, if no power stage axis is open.

5.5.1 Interface Parameters

Several interface parameters can be set in this menu.

RS 232/RS 485 inteface:




Fig. 13: Interface parameter settings

Active COM

Here, the power stage that is connected to the interface, is set.

ServiceBus-Comm searches automatically for available PC interfaces (up to 32). Installed USB --> RS converter interfaces are also found and displayed.

Transmission format

Here, you can set the transmission format of the interface.

Important: These settings must not be changed! They are designed for additional power stages.

Baud rate & Adr.Byte(s)

The **Baud rate** (data per second in KBits) can be selected by clicking the drop down arrow of the box **Baud rate** (values from 9600 to 115200). The value must be compatible with the power stage's baud rate.

The value of the power stage address should be selected in **Adr.:**

Power stage	Address Byte(s)
MCD+	2
PAB+	1
MR8+	2
CCD+	2
CLD+	2
ZMX+	2

Baud rate Autodetect

In **Baud rate Autodetect** ServiceBus-Comm searches for the connected power stages with the preset interface in all possible baud rates (9600 to 115200) and all addresses (0 to 15 or 0 to 31): .

Remark: This search can take some minutes. We recommend to open the function **Search** , if you want to search for the connected power stages with the same baud rate and the same address bytes.

The changes are accepted by and the interface is initialized with the new parameters.

aborts the changes.

CAN Interface:




Fig. 14: Interface parameter settings for CAN

CAN Baud rate setting

The baud rate of the CAN controller (data per second in baud) can be selected by clicking the drop down arrow (125, 250, 500 or 1000). The value must be compatible to the power stage's baud rate.

5.5.2 Monitor

Important:

The menu *Options / Monitor* is a program for the service department. If you want to use *Options / Monitor*, please call phytron's service in any case.

This program menu is used for testing the power stage. You can directly send commands to the connected power stage.

5.5.3 Language

With *Options / Language* you can select the program dialogue in German or English.

5.6 The Menu *Windows*


You can arrange optically the displayed axes windows by the menu *Windows*. The directories of all files are listed after clicking on *Windows*. You can select the active window on screen by mouse click. The active window is marked by ✓.

5.6.1 Cascading Windows


Several open axes files are arranged in a cascading mode by clicking on *Cascading Windows*.

The order of the axes remains unchanged.

Before:



Afterwards:



5.6.2 Tile Windows

The open axes files are placed horizontally by clicking on **Tile Windows**.

5.6.3 Place Symbols

Here, the minimised program windows on the lower screen edge are placed in a row side by side.

5.7 Menu Help ?

5.7.1 About ServiceBus-Comm®

The menu **Options / About ServiceBus-Comm** gives you important information about the program version of ServiceBus-Comm, copyright and phytron's contact info (Fig. 15):



Fig. 15: Information about ServiceBus-Comm

5.7.2 Help

The menu **Options / Help** opens the help function of ServiceBus-Comm.

6 Error Messages

In this appendix are hints on how to handle error messages of ServiceBus-Comm. Messages which do not need any additional information are not contained in this appendix.

Remark:

Error messages resulting in problems with any peripheral device are very often caused by trivial facts like: device is not switched on, cables are missing, cable is defective and so on. Please check these items.

Interface Problems

An interface time out has occurred

Reasons for this problem may be:

- The cabling is wrong (RD and TD pins interchanged).
- The cabling is defective or interrupted.
- The time out selected in ServiceBus-Comm is too short.
- The interface parameters selected in ServiceBus-Comm do not match the power stage type used.
- No power stage connected

Interface cannot be opened

Reason: The interface is already used by another program.

Troubleshooting: Select another interface in menu *Interface parameters*

7 USB Driver Installation



- Administrator authorizations are required for the driver installation.
 - Use a USB cable with a maximum length of 2 metres!
 - To test several USB devices, which are identical in construction, use the same USB port on the PC to avoid changing the COM port number.
- Insert the phytron CD and open the folder **USB Treiber** with Windows Explorer. Select the **.exe** program which goes with your system software and start it by double clicking. The following window is shown on the desktop after a successful installation:



- Connect the power stage directly or via USB converter to the USB port of your PC by USB cable.
- For checking the correct USB driver installation, continue as follows:
Start the device manager by clicking **Start→Settings→System control** and double-click on **System**. Then select the **Device manager** tab. The USB components can be found in **Computer→Ports** and in **Universal Serial Bus Controller**. Here the new USB component is shown: **USB Serial Port (Com X)**
- You'll also find information about the driver installation for the chip FT232R on <http://www.ftdichip.com>.

8 Copyright and Limitation of Warranty

The software ServiceBus-Comm and any documentation delivered with it are protected by copyright law. The manual must not be copied, reproduced, put into machine readable form, neither complete or in parts, without the prior written permission of Phytron-Elektronik GmbH.

ServiceBus-Comm as a freeware product will only give you the right to make backup copies for personal use. However, the program must not be changed nor sold.

Limitation of warranty

The software ServiceBus-Comm and its documentation have been made with great care and have been reproduced under effective controlling measures. Each disk or CD-ROM delivered by Phytron-Elektronik GmbH is checked against viruses by means of a well known virus scan program. Nevertheless there might be mistakes.

We refer to our delivery and payment conditions, in particular to item VII liability and item IX software utilization.

You'll agree to our delivery and payment conditions, if you install, copy or otherwise use the software. If you disagree to these conditions you aren't authorized to install or use the software.

Trade marks

In this manual several trade marks are used which are no longer explicitly marked as trade marks within the text. The lack of these signs may not be used to draw the conclusion that these products are free of rights of third parties. Some product names used herein are for instance

- ServiceBus-Comm is a trade mark of Phytron-Elektronik GmbH.
- Microsoft is a registered trade mark and WINDOWS is a trade mark of the Microsoft Corporation in the USA and other countries.

9 Index

A

Activation 16
Address byte 24
Administrator authorizations 7
Axis failure 15

B

Baud rate 23, 25
Bus operation mode 17

C

Cabling 29
CAN 7, 25
Cascading windows 27
CD 5
Chopper frequency 16
COM Interface 23, 29
Control lamp 14, 17, 20
Copyright 2, 28, 31
Current delay time 16
Current shape 16

D

Default values 15
Defect cabling 29
Degassing time 19

E

EPROM 15
Error 17
Error message 29

F

File 10
Freeware 31

H

Help 28

I

Installation program 5
Installation programm 5
Interface 7
Interface parameters 23

Interface problems 29

L

Language 26

M

Monitor 26

O

Off line 13
Operating system 4
Operation mode 16
Options 23
Overdrive 16

P

Parameter file 13, 14
Power stage status 19, 21
Program library 7
Program version 28
Project 4, 9, 10, 22
Project file 11

R

RAM 4
Rotation 20
RS485 4

S

Search 13
Selection menu 8
Stand alone 16
State line 8
Status bar 12
Status overview 21
System requirements 4

T

Temperature module TEO 18
Test functions 19
Tile windows 28
Tool bar 12
Trade mark 31
Transmission format 23
TreeView 8, 12

U

Update 7
USB 4, 7
USB driver 7, 30
USB interface 7
USB port 30

W

Watchdog 17
Window 27
Working area 8
Working environment 8

Phytron GmbH • Industriestraße 12 • 82194 Gröbenzell, Germany
Tel. +49(0)8142/503-0 • Fax +49(0)8142/503-190 • E-Mail info@phytron.de • www.phytron.de

Phytron, Inc. • 600 Blair Park Road Suite 220 • Williston, VT 05495 USA
Tel. +1-802-872-1600 • Fax +1-802-872-0311 • Email info@phytron.com • www.phytron.com